



Note: Lifting loops are for plant use and ground movement only and are not engineered for overhead use. Extreme caution must be used when lifting planter from lifting loops higher than 12" from ground.

S4842 Square Planter	Width x Length x Height	weight
	48" x 48" x 42"	2860 lbs